



wonderbox.tv

Wonderbox.tv – Installation

This is a general guide for installing and setting up your Android Smart TV Box.

Note: All Android Smart TV Boxes retailed by Wonderbox.tv already have:

- **Automatic date & time switched to On**
- **Time Zone set to the location of the recipient**
- **Unknown sources switched to On**


We've done the work for you!

After connecting your Android Smart TV box to your TV and the mains electricity supply, decide on whether you would like to use an Ethernet (wired) connection or Wi-Fi (wireless). Where practicable, an Ethernet connection is preferable to Wi-Fi and Power Line adaptors are available from many retailers for distributing Ethernet around the home or workplace.


Android Settings menus vary per the device and version of Android. The following screenshots and descriptions are typical.

- **Connecting to Wi-Fi**

From the Android home screen, go to Settings and then Network. Make sure Wi-Fi is ticked, select your Wi-Fi network and input your password exactly.




Click the back button and select Connect Now.




Wait a minute then click the Home Button on your remote.


An alternative Settings menu... Click on Wi-Fi.




Make sure Wi-Fi is On (top right) and select your Wi-Fi network.



Input your password exactly.



Click the back button and select Connect.




Wait a minute then click the Home Button on your remote.


A useful trouble shooting exercise at this stage is to prove your Internet connection by opening your web browser (which can be found on your Android home screen and/or in Apps) and visiting a couple of websites. For example, www.bbc.co.uk and www.sky.com.

- **Date & Time**


From the Android home screen, go to Settings (then Advanced or Other, then More settings, depending on the menu) and Date & Time.




Select Automatic date & time...




...and make sure it is switched to On.



Back Space and select Time.




Choose the appropriate Time Zone.




Back Space to the Settings menu.

- **Allow Unknown Sources (this step will let you install applications outside of Google Play Store).**

Arrow down and select Security & restrictions.



Then Unknown sources.



Make sure Unknown sources is On.




Click the Home Button on your remote.

www.wonderbox.tv


- **Google Play Store (this is optional but signing into Google Play Store will help keep many of your apps up to date and allow you to easily install countless more).**

Google Play Store can be found on your Android home screen and/or in Apps. Click on Play Store.




WWW.WO

You need a Gmail account to sign in. Either use an existing account...



...or create an account directly from Play Store.



Follow the prompts!

We hope you have fun with your Android Smart TV device and if purchased from Wonderbox.tv, please do not forget to leave a review or feedback.

Our website: www.wonderbox.tv

Our email address: info@wonderbox.tv

We always do our best to answer messages as quickly as possible. Please note our usual business hours are 9am to 5pm GMT/BST Monday to Friday except public holidays.

Wonderbox.tv Limited, 71-75 Shelton Street, London , WC2H 9JQ , UK.

www.wonderbox.tv